

ZAZU

Gaia the galaxy star

GALAXY PROJECTOR


WITH SOUNDMACHINE AND CRY SENSOR



SELECT YOUR LANGUAGE




MANUAL




HANDLEIDING



GUIDE
D'UTILISATION



BEDIENUNGS
ANLEITUNG




ANVÄNDAR
MANUAL




BRUKERMANUAL



OHJEKIRJA




BRUGERMANUAL




INSTRUKCJA
OBSŁUGI



MANUAL
DE USUARIO




UŽIVATELSKÝ
MANUÁL



POUŽIVATELSKÁ
PRÍRUČKA




KORISNIČKI
PRIRUČNIK




A NAVODILA
ZA UPORABO



ΕΓΧΕΙΡΙΔΙΟ
ΧΡΗΣΗΣ



HASZNÁLATI
UTASÍTÁS




ПОСІБНИК
КОРИСТУВАЧА




ITALA MANUALE
UTENTE IAN




MANUAL




JUHENDV




ROKASGRĀMATA



MANUAL



УПЪТВАНЕ ЗА
УПОТРЕБА




ИНСТРУКЦИЯ



MANUAL

GALAXY PROJECTOR



ON/OFF button

The big round button is the on/off button and has several functions:

ON

Shortly press the button to switch on light and once more to play music as well. Timer and cry sensor will only become active when the slider is not in the off position.

OFF *both sound, light and cry sensor*

Press and hold the button, light will blink red when done. Light, sound and cry sensor will be shut off.

Change settings

Light

Colour

Shortly press the small button to scroll through all colours.

Brightness

Press and hold to select your preferred brightness: high-medium-low.

Timer

Put the slider in the preferred setting

- OFF: no timer (continuous on)
- 20 minute auto shut-off
- 40 minute auto shut-off

Sound

Melodies

Shortly press the small button to scroll through all melodies: heartbeat, white noise, shushing, lounge, ocean, African sunset, breathing and 3 lullabies.

Volume

Press and hold to select your preferred volume high-medium-low.

Cry sensor

- The cry sensor will activate the last used setting.
- The cry sensor has sensitivity settings:
Low = activates upon loud crying volume
High = activates upon medium/soft crying volume

Reset: If the product is not working properly, press the reset button with a small pin to restart the software.

Power supply

- Ensure the rechargeable battery is fully charged before initial use.
- When battery indicator is blinking, the battery is running low, time to charge it.
- While charging, the indicator light is red. It will switch off once the battery is fully charged, this takes about 2-2.5 hours.
- When finished charging, take out the charger plug.
- Use only the supplied cable to charge the product and insert it into a USB power supply with the following symbols.



Battery life

The battery life varies based on the brightness and volume, but on average it should last at least 9 hours.

⚠ WARNING! SAFETY GUIDELINES

- IMPORTANT! Keep for future reference.
- This ZAZU product is fully compliant with the EU, CA, AU, NZ and USA legislation.
- Please keep the packaging away from small children.
- Never allow your child to play with the power cord.
- Rechargeable battery can only be charged under adult supervision.
- This toy contains batteries that are non-replaceable.
- The connecting lead is low voltage only, but for reliability reasons it should be treated with care.
- For use only with the USB-cable that came with the ZAZU-product.
- The USB cable is not a toy.
- Long cable strangulation hazard.
- Do not place too close to the baby and fixate the plush to the cot with the velcro strap.
- This light does not get warm.
- This product is intended for indoor use and is not water resistant. Please keep dry.
- The plush can be washed by hand and air dried, but remove the module beforehand.
- For cleaning the module do not immerse in water, but wipe with a damp cloth.
- Do not try to disassemble the product if it stops working. Please contact customer service.
- The EC Declaration of Conformity can be requested from the below address: info@zazu-kids.com